

KNX Gateway User Manual

Applicable for the debugging and configuration of KNX Gateway via HDL Studio software, as

well as remote control by ON+ APP

Version: V1.0.0

Published on July 14, 2021



Contents



Legal Statement & Update History



HDL Studio Instruction

Debugging & Configuration of KNX Gateway via HDL Studio......7



Software Introduction

HDL Studio Introduction.....5



1. Legal Statement & Update History

- Legal Statement......4
- Update History......<u>4</u>



1. Legal Statement

HDL has all the intellectual property rights to this document and contents thereof. Reproduction or distribution for third parties are prohibited without written authorization from HDL. Any infringement of HDL's intellectual property rights will be investigated the legal liability.

The contents of this document will be updated as the updates of product versions or other reasons. Unless otherwise agreed upon, this document is to be used as a guidance only. All the statements, information and recommendations in this document makes no warranty expressed or implied.

2. Update History

The form below contains the information of every update. The latest version contains all the updates of all former versions.

No.	Version	Update Information	Date
1	V1.0.0	Initial release	Jul 14, 2021



2. Software Introduction

HDL Studio Introduction.....<u>6</u>

٠

1. HDL Studio Introduction



2. Preparation

During the configuration process of KNX Gateway done on HDL Studio,

the following tools might be included:

- KNX Gateway (Model: M/GWASC.1)
- A computer with HDL Studio
- ON+ Application
- Dedicated KNX cables

*Note:

- ON+ Application supports extranet and local control.
- Please refer to the data sheet attached to the product for the information of installation, wiring, specifications, etc.
- The pictures in this user manual are for reference only and the actual product should prevail.



3. HDL Studio Instruction

•	Log in HDL Studio <u>8</u>	
•	Create Project9	
•	Search Device <u>13</u>	
•	Add Device to 【Device Box】	
•	Building Setting	
•	Group Address Setting20)
•	Upload Project Data to Cloud26	5
•	Log into ON+ for Test27	, _
•	Deliver Project	5





Step 2 —— HDL Studio can be used together with IOT platform, which enables to create and manage projects by Cloud. So there are two options for creating projects, as shown below:



	Option 1	Option 2			
Where to Create	IOT Platform	HDL Studio			
Advantages	Manage and Control by IOT Platform	No need to log in/sign up, you can locally create an manage projects			
Applicable for	Applicable for large-scale projects, batch residential projects	Applicable for single project, as well as for creating personal debugging/testing templates			













HDL

- 0 ×

8

Upload Project

IP: 172.16.4.175 Online: 0 Offline: 0

Cancel



Step 3 — After making sure the current IP and device IP be kept at the same segment, proceed searching device.



① Click "Searc	ch"		② Now all o shown he	levices search ere	ed can be ●			
File Tool Help								- A X
Copen Import Search Device ca	talogue IP Confiç	j. Light scene Sce	ne Automation Tr	ansfer Data		Uplo	ad Project	8
Device Box Building =	Configura	tion Search dev	ice			IP: 19	92.168.1.3	Online: 0 Offline: 0
Q +	Q Search Dev	ice						
<u>₹</u> (0/0)			1.					_
NOT ASSIGNED(0/0)	No.	Device model	Device name	Device remark	Device Type	Subnet	Device I	Firmware versio
	0 1	M/GWASC.1	Link gateway		Gateways	0	0	UnRead
								1/









Note: Only one gateway can be added for the corresponding project.

Click "Device Box" to check all devices

*"Device Box" refers to electric boxes.







Click this gateway

пе тоот негр							- 0
Dpen Import Search	Device cat) 🕂 🔊	Light scene Scene Automation	Transfer Data		CD Upload Proje	_{ct} 🥐
ome 1	×						
Device Box Building	=	Configuration	Search device			IP: 192.168.1.3	Online: 1 Off
	+	Basic setting	Functions Drivers			M/GWASC.1	Model No.
Home 1(1/1)						Link gateway	Device name
						00.07.2E.68.94.B8.17.02	MAC
Gateways(1/1)		Network address		Connection		More	
(Link gateway)		OHCP		Connect type:	Local 💌	Pointing device	í.
		Host IP:	192 . 168 . 1 . 5	Project group:		Clausdate	
		Router IP:	192 . 168 . 1 . 1	Project name:	维港半岛15号楼	Clear data	
		Mask:	255 . 255 . 255 . 0	Designer:		Data backup	
		IP MAC:	02 . 81 . C6 . BB . 64 . 54	Website:		Recover data	1
		DNS1:	202 . 96 . 128 . 86	Connection of Gateway	y and Cloud: Offline	🛛 Master	
		20102	114 114 114 114	Connection of Gateway	y and Devices: Online		
		UNSZ:		Date and time		Project Information	n
				Date(YYYY/MM/DD):	2021-07-15	Home id:	0
				Time(HHimmics);	15 . 0 . 5	C 1 1	1 I I







HDI





Step 6 —— Group address setting After assigning area and configuration function, back to "Device Box" and proceed as below: Back to "Device Select "Function" (2) (1)Box" and select this gateway Assign area for the function (3) Click "Add" **b** | File Tool Help - 0 × * 2 2 Ŧ (P) -8 8 Search Device catalogue IP Config. Scene Automation Transfer Data Upload Project Open Import Home 1 × Ξ. Configuration Search device Device catalogue IP: 172.16.4.175 Online: 0 Offline: 1 Device Box Building Functions Drivers Basic setting Q + M/GWASC.1 Model No. Read Link gateway Device name 7 Home 1(1/1) NOT ASSIGNED(0/1) ▼ 🔲 Gateways(0/1) Function list Group address Add function Light(4) Function name: Function name: Light туре Zone No. Name NOT ASSIGNED * Area: Function type: Lighting Light(1) Lighting 1F-Room1 1 * Lighting type Switch Lighting Function type 2 Light(2) Lighting Switch ting type On/Off: 0/0/5 NOT ASSIGNED 0/1/5 3 Light(3) Lighting bff 0/0/4 Status on/off: 1F 0/1/4 4 us on/off: Add: Room1 Light(4) Lighting Room2

Group address is kept the same as that in KNX ETS software.

*As for KNX ETS group address, please referr to next page.



Step 6 —— Group address setting



As below shown, in KNX ETS, the devices managed by the gateway can be configured with group address which is the same as the gateway channel.

Select the device as needed

Ĺ						● Li	st of g	roup addres	S			
ETS5™ - New project	-						10000	-				0 X
FTS Edit Workplace Commissioning Diagn	ostics Apps Wi	ndow										~ (
a Close Project	Reports	- Workplace • Catalog	as Diagnostics									
Topology *	1 100	i Loning i							∧ ₫ ×	Propertie	25	
🖡 Add Channels 🔹 🗙 Delete 🛨 Download 🔹 I	🚺 Info 🔹 👩 Res	et 🖇 Unload 🔹 📾 Print						Search	Q	i i i i i i i i i i i i i i i i i i i		
Topology Backbone	• Number *	Name	Object Function De	scription Group Address	Length	CRWTU	Data Type	Priority		Settings	Comments Inform	mation
Dynamic Folders	■2 10	Output A	Channel output	0/0/1	1 bit	C - W - U	switch	Low		Name		
1 New area	■# 11	Output A	Always response switch status	0/1/1	1 bit	C R - T -	switch	Low		M/R8.16.1		
10.246 M/09.16.1	■2 30	Output B	Channel output	0/0/2	1 bit	C - W - U	switch	Low		Induidual Add	lease	
1.0.240 M/R6.10.1	■2 31	Output B	Always response switch status	0/1/2	1 bit	C R - T -	switch	Low		Individual Add	10 out *	Deals
■ 2 10: Output A - Channel output	■2 50	Output C	Channel output	0/0/3	1 bit	C - W - U	switch	Low			1.0 . 246 *	Park
11: Output A - Always response switch status	■2 51	Output C	Always response switch status	0/1/3	1 bit	C R - T -	switch	Low		Description		
■之 30: Output B - Channel output	■2 70	Output D	Channel output	0/0/4	1 bit	C - W - U	switch	Low				
■ \$ 21: Output B - Always response switch status	■₽ 71	Output D	Always response switch status	0/1/4	1 bit	C R - T -	switch	Low				
50: Output C - Channel output	■≵ 90	Output E	Channel output	0/0/5	1 bit	C - W - U	switch	Low				
	■2 91	Output E	Always response switch status	0/1/5	1 bit	C R - T -	switch	Low		Last Modified	2021-06-06 10:31	
⇒ 51: Output C - Always response switch status	■2 110	Output F	Channel output	0/0/6	1 bit	C - W - U	switch	Low		Last Download	led 2021-06-06 10:37	
■ 2 70: Output D - Channel output	■之 111	Output F	Always response switch status	0/1/6	1 bit	C R - T -	switch	Low		Serial Number	RDER-06D773ER	
71: Output D - Always response switch status	1 30	Output G	Channel output	0/0/7	1 bit	C - W - U	switch	Low		Scharmanisch	0010.30077320	
■之 90: Output E - Channel output	Z 131	Output G	Always response switch status	0/1/7	1 bit	C R - T -	switch	Low		Status		
■	■ Z 150	Output H	Channel output	0/0/8	1 bit	C - W - U	switch	Low		Unknown		
Z 110: Output F - Channel output	■ ∠ [151	Output H	Always response switch status	0/1/8	1 bit	C R - T -	switch	Low				
■												
2 130: Output G - Channel output												
■2 131: Output G - Always response switch status												
150: Output H - Channel output												
■ 151: Output H - Always response switch status												







Step 6 —— After completing the previous steps, proceed scene setting.







Step 6 —— After completing the previous steps, proceed scene setting.







Step 6 — After completing the previous steps, proceed scene setting.







Step 7 —— Upload data to Cloud after completing settings.



Click "Upload Project"

(1)

*It is OK to proceed settings when there is no external network; while uploading data to Cloud, please make sure there is valid extranet.

b File Tool Help Ο× 2 2 Ŧ -E. Scene Open Import Search Device catalogue IP Config. Automation Transfer Data Upload Project X Building Ξ IP: 172.16.4.175 Online: 0 Offline: 1 Configuration Search device Device catalogue Device Box Basic setting Functions Drivers Q M/GWASC.1 Model No. Read Link gateway Device name Home 1(1/1) ▼ NOT ASSIGNED(0/1) ▼ 🗍 Gateways(0/1) Network address More Connection MQTT Connect type: DHCP 192 . 168 . 10 . 250 Host IP: Project group: 192 . 168 . 10 . 1 Project name Router IP: Notes Designe 255 . 255 . 255 . 0 Mask: Are you sure to upload the project to cloud? Website 0.0.0.0.0.0 IP MAC: Connect Don't show it again. 114 . 114 . 114 . 114 DNS1: (2) Click "Confirm" 114 . 114 . 114 . 114 Cancel DNS2: Date and time **Project Informatio** Date(YYYY/MM/DD): 2021-07-15 Home id: Time(HH:mm:ss) Gateway id: Geographical position Latitude: 39.54 Longitude: 116.25



Step 8 — After uploading data, proceed logging in ON+ APP for testing.



Set the function needed as favorites then proceed testing in Home page.





Step 8 —— Now please inform the relevant administrator to log in IOT platform and proceed project delivery.







(1)

HDL

◎ 项目管理

匝 模版管理

Step 8 — Now please inform the relevant administrator to log in IOT platform and proceed project delivery.

Select "项目管理 (Project Management)"

 \rightarrow Select residential type



(2) Select the project as needed, click "deliver QR code". Show it to the residence owner for scanning (see next page for more details). *The QR code is valid for the first scanning. Since then, it is bound to the administrator's account by default.

DL'	数暂运营平台 🗸			♦ Hi~13211069159 ∨
印度建	project management / residential project			
家居项目	project count (个) to be debu	agged (个) debugging (个) 0	to be accepted (个)	个) delivered (个) 4
地产项目				
酒店项目	input project number	input project name	please select region V	select system protocol
公建项目	select debug status	select debug personnel	start time ~ end time	select project sub-type
載版管理	create project			query reset
	project number project name project sub-type	region full address debug start time	debug end time system protocol debug status	operation
	R1625820212768 Home 1	China-Guangdong- Guangzhou	- Buspro completed	distribute debug deliver QR code

How to Scan Deliver QR Code





Home

Category

Smart

Individual

<	Personal Center				
	÷				
Name	HDL				
QR code	90 9%	>			
Email	Not bound	>			
Phone	13******13	>			
Change pa	ssword	>			
Add reside	nce	<u>-</u> .		-	
Unlock sett Set passwor ID to protect	ing d, gesture, fingerprint or face your privacy.	>	•	(3)	Click "Add residence
Server info	rmation	>			
	Log out				