
Wiring diagram



UV switch can be used to play songs.

First: select a play list
Second: select a song in play list
Third: Play or not.

NO.	UV switch No	Function
1	1～149	ON: select a song in play list (Song No: 1-148) OFF: do nothing
2	150～200	ON: select a play list (play list No 0-50) OFF: do nothing
3	201	ON: Play OFF: Stop
4	202	ON: Stop All OFF: do nothing
5	203	Change a play list ON: Next OFF: Pre
6	204	Change a song ON: Next OFF: Pre
7	205	Control audio voice ON: UP OFF: DOWN
8	206	TREBLE ON: UP OFF: DOWN
9	207	BASS ON: UP OFF: DOWN
10	208	ON: Play music on SD-Card
11	209	ON: Play music on FTP server
12	210	ON: Radio
13	211	ON: Audio-in
14	215	Voice 63(Min)
15	216	Voice 55
16	217	Voice 47
17	218	Voice 39
18	219	Voice 28
19	220	Voice 20
20	221	Voice 15
21	222	Voice 10
22	223	Voice 5
23	224	Voice 0 (Max)