

# Datasheet

1-Port IP Interface HDL-MBUS01IP.431

#### **Parameters**

Electrical Parameters:			
Working voltage	DC15~30V		
Buspro power consumption	40mA/DC24V		
Signal interface	HDL Buspro, RJ45		
RJ45 connection	RJ45-UDP/IP network		
	inter face		
Environmental Conditions:			
Working temperature	-5°C~45°C		
Working relative humidity	Up to 90%		
Storage temperature	-20°C~+60°C		
Storage relative humidity	Up to 93%		
Approved			
CE			
RoHS			
Product Information :			
Dimensions	72×90×66 (mm)		
Weight	124g		
Housing material	Nylon, PC		
Installation	35mm DIN rail installation		
Protection degree	IP20		

## HDL Buspro Definition for Cable

CAT5/CAT5E	HDL Buspro	HDL Buspro/KNX
Brown/ Orange	DC24V	Red
Brown white/ Orange white	СОМ	Black
Blue white/ Green white	DATA-	White
Blue/ Green	DATA+	Yellow

#### **Important Notes**

- Buspro cable CAT5E or HDL Bus/KNX cable.
- Buspro Connection Series connection (hand-in -hand).
- Make sure that MAC and IP address of all IP devices are unique in the same network.
- Installation DB box.

#### **Overview**



HDL-MBUS01IP.431 1-port IP interface is the gateway between HDL Buspro system and Ethernet. It can realize the bidirectional data transmission between HDL Buspro and Ethernet.

### **Functions**

- Bidirectional data exchange between HDL Buspro and Ethernet.
- Supports local control, p2p control, remote control (local control by default), local network.
- Allows maximum 4 devices to connect this module for remote control, such as iPad, iPhone, Touchlife, HDL Buspro software and so on.
- Intelligent data exchange , minimize data traffic.
- Communication: HDL Buspro, IP network.

#### Installation Step


- 35mm DIN rail installation, inside DB Box.
- Connect HDL Buspro cable, RJ45 cable.
- Check the connection, avoid any mistakes.





# Datasheet |1-Port IP Interface HDL-MBUS01IP.431

## **Dimensions and Wiring**



RJ45 connection: UDP/IP interface

#### Setting of Network Parameter :

1-port IP interface has a default IP-192 168 10.250 and 6000 for port. Please change the user PC IP address into the same IP segment.

Steps for change IP address :

- Modify the IP address of the user PC into 192.168.10.\*\* ( \*\* means any ) . 1.
- 2. Open the "HDL Buspro Set Up tool", find the device, change the IP address into the same IP segment of the user PC. Finish and save.
- Change the IP address of the user PC back to previous IP. 3.
- 4. Power the device off, then the new IP address will be available after power on.

### Safety precaution

The screw down strength should not exceed 0.4Nm 

- Installation Position: Distribution box (DB)
- Do not make wrong connection on Buspre interface, it will damage the Buspro interface of this module
- Never let liquids get into the module, it will damage this device
- Do not get AC power into Bus wire, it will damage all devices in the system
- Avoid contact with liquids and aggressive gases

#### Packing List

Datasheet\*1 / MBUS01IP.431 \*1

Professional Home and Building Automation www.hdlautomation.com(V1.0-150717)

